

MagicWatch WPS910 & WPS900F Application & Functionality Q3/2017

Manufacturer	Model	Note	Speed	Ignition	Reverse	Wire connections	Position	
<b>Alfa Romeo</b>	Baris - 2008		YES	YES	YES	CAN HIGH - R = PINK-BLACK CAN LOW - S PINK-WHITE	Connector: BLUE 36 pin (green) at rear of fuse box. Position (R and L): Nr. 6 and Nr. 5.	
	Giulietta - 2010		YES	YES	YES	CAN HIGH BLUE CAN LOW WHITE	Connected to connector C8D on left underneath steering column. Position (R and L): Nr. 1 and Nr. 2.	
	GT - 2004		YES	YES	YES	CAN HIGH BLUE CAN LOW WHITE	Connector: BLUE (red retention), 40pin mated G on front of fuse box to left of steering wheel. Position (R and L): Nr. 21 and Nr. 2.	
	Mio - 2008		YES	YES	YES	CAN HIGH BLUE CAN LOW WHITE	Connected to connector C8D on left underneath steering column. Position (R and L): Nr. 1 and Nr. 2.	
	147		YES	YES	YES	CAN HIGH PINK-BLACK CAN LOW PINK-WHITE	Connector: BLUE (red retention), 40pin mated G on front of fuse box to left of steering wheel. Position (R and L): Nr. 21 and Nr. 2.	
	159 - 2006		YES	YES	YES	CAN HIGH PINK-BLACK CAN LOW PINK-WHITE	Connector: BLUE 36 pin (green) at rear of fuse box. Position (R and L): Nr. 6 and Nr. 5.	
	<b>Aston Martin</b>	Vantage - 2008		YES	YES	YES	CAN H + RED / BROWN CAN L + RED / BLACK	The CAN wiring is located at the Body Diagnostic socket, drivers side, bottom of the dash panel. There are 4 diagnostic sockets named Body & C8D.
		DB9 - 2006		YES	YES	YES	CAN H = Pin 3 CAN L = Pin 11	The CAN wiring is located at the C8D socket, drivers side, bottom of the dash panel.
		<b>Audi</b>	A1 - 2010		YES	(YES)	YES	CAN H + ORANGE / GREEN CAN L + ORANGE / BROWN
	A3 - 2002			YES	YES	YES	CAN HIGH ORANGE-PURPLE CAN LOW ORANGE BROWN	Connector: 12 pin BLACK connector G connected to black control unit fastened underneath dashboard, driver's side. Position (R and L): Nr. 8 and Nr. 7.
A3 - 2010			YES	(YES)	YES	CAN H + ORANGE / GREEN CAN L + ORANGE / BROWN	Connector: BROWN 52 pin the connector is located the lower drivers side under panel. Position (R and L): Nr. 13 and Nr. 16.	
A3 - 2013			YES	(YES)	YES	CAN H + ORANGE / GREEN CAN L + ORANGE / BROWN	Connector: BLACK 73 pin the connector is located the lower drivers side under panel Position (R and L): Nr. 8 and Nr. 7. Also found the wiring harness coming from the driver door grommet.	
A4 - 2002			YES	YES	YES	CAN HIGH ORANGE-GREEN CAN LOW ORANGE BROWN	Connector: GRE VIOLET 35 pin connector connected to Black control unit fastened underneath dashboard, driver's side. Position (R and L): Nr. 13 and Nr. 12.	
A4 - 2005			YES	(YES)	YES	CAN HIGH ORANGE-GREEN CAN LOW ORANGE BROWN	Connector: GRE VIOLET 35 pin connector connected to Black control unit fastened underneath dashboard, driver's side. Position (R and L): Nr. 13 and Nr. 12.	
A4 - 2007			YES	(YES)	YES	CAN HIGH ORANGE-GREEN CAN LOW ORANGE BROWN	Connector: LIGHT BROWN, 16pin connected to electronic module underneath the dashboard, driver's side, at top rear clutch pedal. Pos. (R and L): Nr. 15 and No. 14, or Wire bundle to left of steering wheel behind lower plastic cover of dashboard.	
A4 - 2015	NEW		YES	(YES)	YES	CAN HIGH ORANGE-GREEN CAN LOW ORANGE BROWN	Connector: LIGHT BROWN, 16pin connected to electronic module underneath the dashboard, driver's side, at top rear clutch pedal. Pos. (R and L): Nr. 15 and No. 14, or Wire bundle to left of steering wheel behind lower plastic cover of dashboard.	
A5 - 2007			YES	(YES)	YES	CAN HIGH ORANGE-GREEN CAN LOW ORANGE BROWN	Connector: LIGHT BROWN, 16pin connected to electronic module underneath the dashboard, driver's side, at top rear clutch pedal. Pos. (R and L): Nr. 15 and No. 14, or Wire bundle to left of steering wheel behind lower plastic cover of dashboard.	
A5 - 2016	NEW		YES	(YES)	YES	CAN HIGH ORANGE-GREEN CAN LOW ORANGE BROWN	Connector: LIGHT BROWN, 16pin connected to electronic module underneath the dashboard, driver's side, at top rear clutch pedal. Pos. (R and L): Nr. 15 and No. 14, or Wire bundle to left of steering wheel behind lower plastic cover of dashboard.	
A6 - 2002			YES	(YES)	YES	CAN HIGH ORANGE-PURPLE CAN LOW ORANGE BROWN	The interface is installed to the CAN wiring at the audio connector. Connector: LIGHT BROWN, 16pin connected to electronic module underneath the dashboard, driver's side, at top rear clutch pedal. Pos. (R and L): Nr. 15 and No. 14.	
A6 - 2011			YES	(YES)	YES	CAN HIGH ORANGE-GREEN CAN LOW ORANGE BROWN	Connector: LIGHT BROWN, 16pin connected to electronic module underneath the dashboard, driver's side, at top rear clutch pedal. Pos. (R and L): Nr. 15 and No. 14.	
A7 - 2011			YES	(YES)	YES	CAN HIGH ORANGE-GREEN CAN LOW ORANGE BROWN	Remove the audio unit. The interface is installed to the CAN wiring at the audio connector.	
A8 - 2003			YES	YES	YES	CAN HIGH ORANGE-GREEN CAN LOW ORANGE BROWN	Connector: BROWN 52 pin the connector is located the lower drivers side under panel. Position (R and L): Nr. 13 and Nr. 16.	
A8 - 2011			YES	YES	YES	CAN H + ORANGE / GREEN CAN L + ORANGE / BROWN	Connector: BROWN 52 pin the connector is located the lower drivers side under panel. Position (R and L): Nr. 13 and Nr. 16.	
Q3 - 2011			YES	(YES)	YES	CAN HIGH ORANGE-GREEN CAN LOW ORANGE BROWN	Connector: LIGHT BROWN, 16pin connected to electronic module underneath the dashboard, driver's side, at top rear clutch pedal. Pos. (R and L): Nr. 15 and No. 14.	
Q5 - 2008			YES	(YES)	YES	CAN HIGH ORANGE-GREEN CAN LOW ORANGE BROWN	Connector: LIGHT BROWN, 16pin connected to electronic module underneath the dashboard, driver's side, at top rear clutch pedal. Pos. (R and L): Nr. 15 and No. 14.	
Q5 - 2017	NEW		YES	(YES)	YES	CAN HIGH ORANGE-GREEN CAN LOW ORANGE BROWN	Connector: LIGHT BROWN, 16pin connected to electronic module underneath the dashboard, driver's side, at top rear clutch pedal. Pos. (R and L): Nr. 15 and No. 14.	
Q7 - 2008			YES	(YES)	YES	CAN HIGH ORANGE-GREEN CAN LOW ORANGE BROWN	Connector: LIGHT BROWN, 16pin connected to electronic module underneath the dashboard, driver's side, at top rear clutch pedal. Pos. (R and L): Nr. 15 and No. 14.	
Q7 - 2015	NEW		YES	(YES)	YES	CAN HIGH ORANGE-GREEN CAN LOW ORANGE BROWN	Connector: BLACK, 73pin connected to electronic module underneath the dashboard, driver's side, near clutch pedal. Pos. (R and L): pin 40 and pin 41, or Wire bundle to left of steering wheel behind lower plastic cover of dashboard.	
RA - 2007		YES	(YES)	YES	CAN HIGH ORANGE-GREEN CAN LOW ORANGE BROWN	Connector: 12 pin BLACK connector G connected to black control unit fastened underneath dashboard, driver's side. Position (R and L): Nr. 8 and Nr. 7.		
RS - 2007		YES	(YES)	YES	CAN HIGH ORANGE-GREEN CAN LOW ORANGE BROWN	Connector: LIGHT BROWN, 16pin connected to electronic module underneath the dashboard, driver's side, at top rear clutch pedal. Pos. (R and L): Nr. 15 and No. 14.		
S6 - 2002		YES	(YES)	YES	CAN HIGH ORANGE-GREEN CAN LOW ORANGE BROWN	Connector: GRE VIOLET 35 pin connector connected to Black control unit fastened underneath dashboard, driver's side. Position (R and L): Nr. 13 and Nr. 12.		
TT - 2002		YES	YES	YES	CAN HIGH ORANGE-PURPLE CAN LOW ORANGE BROWN	The interface is installed to the CAN wiring at the audio connector.		
TT - 2007		YES	(YES)	YES	CAN H + ORANGE / GREEN CAN L + ORANGE / BROWN	Connector: BROWN 52 pin the connector is located the lower drivers side under panel. Position (R and L): Nr. 13 and Nr. 16.		
TT - 2014	NEW	YES	(YES)	YES	CAN H + ORANGE / GREEN CAN L + ORANGE / BROWN	Connector: BROWN 52 pin the connector is located the lower drivers side under panel. Position (R and L): Nr. 13 and Nr. 16.		
<b>BMW</b>	1 Series(E81)(E88) 2005		YES	(YES)	YES	CAN HIGH ORANGE-GREEN CAN LOW GREEN	Connector: BLACK GREY 51 pin connected to light electronic module behind the kick plate, driver's side. Position (R and L): Nr. 48 and Nr. 45.	
		1 Series(F20)(F21) 2012		YES	(YES)	YES	CAN HIGH ORANGE-GREEN CAN LOW GREEN	Remove the lower passenger under glove box trim, locate the FEM (Forward Electrical Module) near the 'A' pillar. The CAN BUS wiring is a twisted pair of wires. Connector: WHITE 54 pins Position (R and L): Nr. 34 and Nr. 33.
	2 Series(F20)(F46) 2014	NEW	YES	(YES)	YES	CAN HIGH BLUE-RED CAN LOW RED	Remove the lower passenger under glove box trim, locate the FEM (Forward Electrical Module). The CAN BUS wiring is a twisted pair of wires. Connector: 12 pins WHITE Number 10. Position (R and L):	
			YES	YES	YES	CAN H - YELLOW-BLACK CAN L - YELLOW-BROWN	Connected behind to speedometer assembly, the Can-bus wiring is a twisted pair of wires.	
	3 Series(E48) 2002		YES	YES	YES	CAN H - YELLOW-BLACK CAN L - YELLOW-BROWN	Connected behind to speedometer assembly, the Can-bus wiring is a twisted pair of wires.	
	3 Series(E90) 2005		YES	(YES)	YES	CAN HIGH ORANGE-GREEN CAN LOW GREEN	Remove the lower passenger under glove box trim, locate the FEM (Forward Electrical Module) near the 'A' pillar. The CAN BUS wiring is a twisted pair of wires. Connector: WHITE 54 pins Position (R and L): Nr. 34 and Nr. 33.	
	3 Series(F30) 2012		YES	(YES)	YES	CAN HIGH ORANGE-GREEN CAN LOW GREEN	Connector: BLACK 41 pin connected to white electronic module "CAS", fastened to the left of steering column. Position (R and L): Nr. 35 and Nr. 26.	
	5 Series(E60) 2003		YES	YES	YES	CAN L - YELLOW CAN HIGH ORANGE-GREEN CAN LOW GREEN	Connector: LIGHT BLUE (black retention) connected to electronic module (aluminum case), fastened to the left of the steering column.	
	5 Series(F10)(F11) 2010		YES	(YES)	YES	CAN H - BLACK CAN L - YELLOW	Connector: WHITE, 8pin connected to the back electronic module "CAS", fastened to the left of steering column. Position (R and L): Nr. 14 and Nr. 33.	
	6 Series(E63) 2004		YES	(YES)	YES	CAN HIGH ORANGE-GREEN CAN LOW GREEN	Connector: LIGHT BLUE (black retention) connected to electronic module (aluminum case), fastened to the left of the steering column.	
	6 Series(F12) 2011	NEW	YES	(YES)	YES	CAN HIGH ORANGE-GREEN CAN LOW GREEN	Connector: LIGHT BLUE (black retention) connected to electronic module (aluminum case), fastened to the left of the steering column.	
	7 Series(F51) 2008	NEW	YES	(YES)	YES	CAN HIGH ORANGE-GREEN CAN LOW GREEN	Connector: LIGHT BLUE (black retention) connected to electronic module (aluminum case), fastened to the left of the steering column.	
	X1(E64) 2009		YES	(YES)	YES	CAN HIGH ORANGE-GREEN CAN LOW GREEN	Connector: BLACK GREY 51 pin connected to light electronic module behind the kick plate, driver's side. Position (R and L): Nr. 48 and Nr. 45.	
	X1(F48) 2015	NEW	YES	(YES)	YES	CAN HIGH BLUE-RED CAN LOW RED	Remove the lower passenger under glove box trim, locate the FEM (Forward Electrical Module). The CAN BUS wiring is a twisted pair of wires. Connector: 12 pins WHITE Number 10. Position (R and L):	
	X3(E40) 2003		YES	YES	YES	CAN H - YELLOW-BLACK CAN L - YELLOW-BROWN	Connected behind to speedometer assembly, the Can-bus wiring is a twisted pair of wires. Or Connector: White 12 pins behind the glove compartment passenger side. Position (R and L): Nr. 5 and Nr. 6.	
	X3(F25) 2011		YES	YES	YES	CAN HIGH ORANGE-GREEN CAN LOW GREEN	Connector: LIGHT BLUE (black retention) connected to electronic module, fastened to the left of the steering column.	
	X4(F28) 2014	NEW	YES	YES	YES	CAN H - YELLOW-BLACK CAN L - YELLOW-BROWN	Connected behind to speedometer assembly, the Can-bus wiring is a twisted pair of wires. Or Connector: White 12 pins behind the glove compartment passenger side.	
	X5(E33) 2006		YES	YES	YES	CAN HIGH ORANGE-GREEN CAN LOW GREEN	Connector: BLACK 41 pin connected to white electronic module "CAS", fastened to the left of steering column. Position (R and L): Nr. 35 and Nr. 26.	
	X5(E70) 2007		YES	(YES)	YES	CAN HIGH ORANGE-GREEN CAN LOW GREEN	Connector: LIGHT BLUE (black retention) connected to electronic module (aluminum case), fastened to the left of the steering column.	
	X5(F15) 2013	NEW	YES	(YES)	YES	CAN HIGH ORANGE-GREEN CAN LOW GREEN	Connector: LIGHT BLUE (black retention) connected to electronic module (aluminum case), fastened to the left of the steering column.	
X6(E71) 2008		YES	YES	YES	CAN HIGH ORANGE-GREEN CAN LOW GREEN	Connector: BLACK 41 pin connected to white electronic module "CAS", fastened to the left of steering column. Position (R and L): Nr. 35 and Nr. 26.		
X6(F16) 2014	NEW	YES	YES	YES	CAN HIGH ORANGE-GREEN CAN LOW GREEN	Connector: LIGHT BLUE (black retention) connected to electronic module (aluminum case), fastened to the left of the steering column.		
Z4(E40) 2003		YES	YES	YES	CAN H - YELLOW-BLACK CAN L - YELLOW-BROWN	Connected behind to speedometer assembly, the Can-bus wiring is a twisted pair of wires.		
<b>Cadillac</b>	Escalade - 2006		YES	YES	YES	CAN H - BEIGE-BLACK PIN 6 CAN L - BEIGE PIN 14	Connected to connector C8D on left underneath steering column. Position (R and L): Nr. 8 and No. 14, or (No. 1 and G.N.D.)	
<b>Chevrolet</b>	Aveo - 2011		YES	(YES)	YES	CAN HIGH PIN 1 CAN LOW GND	Connected to connector C8D on left underneath steering column. Position (R and L): Nr. 1 and G.N.D.	
	Camaro - 2009		YES	(YES)	YES	CAN H - BROWN-BLACK PIN 6 CAN L - BROWN-BLACK PIN 8	Connected to connector C8D on left underneath steering column. Position (R and L): Nr. 8 and No. 14, or (No. 1 Green and G.N.D.)	
	Captiva - 2007 (2011)		YES	(YES)	YES	CAN H - BROWN-BLACK PIN 6 CAN L - BROWN PIN 14	Connected to connector C8D on left underneath steering column. Position (R and L): Nr. 8 and No. 14, or (No. 1 and G.N.D.)	
	Coselco - 2007		YES	YES	YES	CAN HIGH ORANGE PIN 1 CAN LOW BROWN PIN 14	Connected to connector C8D on left underneath steering column. Position (R and L): Nr. 1 and G.N.D.	
	Cruze - 2010		YES	(YES)	YES	CAN L - GND CAN H - BROWN-BLACK PIN 6	Connected to connector C8D on left underneath steering column. Position (R and L): Nr. 8 and No. 14, or (No. 1 and G.N.D.)	
	Equinox - 2006		YES	YES	YES	CAN L - BROWN PIN 14 CAN HIGH ORANGE PIN 1	Connected to connector C8D on left underneath steering column. Position (R and L): Nr. 8 and No. 14, or (No. 1 and G.N.D.)	
	HRV - 2006		YES	(YES)	YES	CAN HIGH PIN 1 CAN LOW GND	Connected to connector C8D on left underneath steering column. Position (R and L): Nr. 1 and G.N.D.	
	Malibu - 2008		YES	(YES)	YES	CAN H - PIN 6 CAN L - BROWN PIN 14	Connected to connector C8D on left underneath steering column. Position (R and L): Nr. 8 and No. 14, or (No. 1 and G.N.D.)	
	Onix - 2010		YES	(YES)	YES	CAN HIGH GREEN PIN 1 CAN LOW GND	Connected to connector C8D on left underneath steering column. Position (R and L): Nr. 1 and G.N.D.	
	Spark - 2010		YES	(YES)	YES	CAN H - BROWN-BLACK PIN 6 CAN L - BROWN PIN 14	Connected to connector C8D on left underneath steering column. Position (R and L): Nr. 8 and No. 14, or (No. 1 and G.N.D.)	
	Volt - 2011		YES	(YES)	YES	CAN H - PIN 6 CAN L - PIN 14	Connected to connector C8D on left underneath steering column. Position (R and L): Nr. 8 and No. 14, or (No. 1 and G.N.D.)	
	<b>Chrysler</b>	300C		YES	(YES)	YES	CAN H + WHITE / ORANGE CAN L + WHITE / RED	The CAN wiring is located at the radio wiring connector. Remove the dash face panel (striped) and install the radio for access.
		300C - 2011		YES	(YES)	YES	CAN H + GREEN CAN L + WHITE	The CAN wiring is located at the radio wiring connector. Remove the dash face panel (striped) and install the radio for access. The CAN wiring cannot be tested at the shop.





MagicWatch WPS910 & WPS900F Application & Functionality 03/2017

Manufacturer	Model	Note	Speed	Ignition	Reverse	Wire connections	Position
<b>Leviss</b>							
	H200 - 2006		YES	YES	YES	CAN H + Pin 6 CAN LO - Pin 14	Connected to connector OBD on left underneath steering column. Position (R and L) No. 6 and No. 14.
	rs 390 - 2009		YES	YES	YES	CAN H + Pin 6 CAN LO - Pin 14	Connected to connector OBD on left underneath steering column. Position (R and L) No. 6 and No. 14.
	rs 4004 - 2009		YES	YES	YES	CAN H + Pin 6 CAN LO - Pin 14	Connected to connector OBD on left underneath steering column. Position (R and L) No. 6 and No. 14.
<b>Maserati</b>							
	Gran Turismo 2007		YES	YES	YES	CAN HIGH: N 6 PINK-BLACK CAN LOW: N 5 PINK-WHITE	Connector BLUE 36 pin (green part) at rear of fuse box. Position (R and L) No. 5 and No. 6.
<b>Mazda</b>							
	2 - 2003		YES	YES	YES	CAN H + Pin 6 CAN LO - Pin 14	Connected to connector OBD on left underneath steering column. Position (R and L) No. 6 and No. 14.
	2 - 2007	NEW	YES	YES	YES	CAN H + Pin 6 CAN LO - Pin 14	Connected to connector OBD on left underneath steering column. Position (R and L) No. 6 and No. 14.
	2 - 2014	NEW	YES	YES	YES	CAN H + Pin 6 CAN LO - Pin 14	Connected to connector OBD on left underneath steering column. Position (R and L) No. 6 and No. 14.
	3 - 2004		YES	YES	YES	CAN H + Pin 6 CAN LO - Pin 14	Connected to connector OBD on left underneath steering column. Position (R and L) No. 6 and No. 14.
	3 - 2014		YES	YES	YES	CAN H + Pin 6 CAN LO - Pin 14	Connected to connector OBD on left underneath steering column. Position (R and L) No. 6 and No. 14.
	5 - 2005		YES	YES	YES	CAN H + Pin 6 CAN LO - Pin 14	Connected to connector OBD on left underneath steering column. Position (R and L) No. 6 and No. 14.
	5 - 2010		YES	YES	YES	CAN H + Pin 6 CAN LO - Pin 14	Connected to connector OBD on left underneath steering column. Position (R and L) No. 6 and No. 14.
	6 - 2005		YES	YES	YES	CAN H + Pin 6 CAN LO - Pin 14	Connected to connector OBD on left underneath steering column. Position (R and L) No. 6 and No. 14.
	6 - 2012	NEW	YES	YES	YES	CAN H + Pin 6 CAN LO - Pin 14	Connected to connector OBD on left underneath steering column. Position (R and L) No. 6 and No. 14.
	CX-3 - 2016	NEW	YES	YES	YES	CAN H + Pin 6 CAN LO - Pin 14	Connected to connector OBD on left underneath steering column. Position (R and L) No. 6 and No. 14.
	CX-5 - 2012		YES	YES	YES	CAN H + Pin 6 CAN LO - Pin 14	Connected to connector OBD on left underneath steering column. Position (R and L) No. 6 and No. 14.
	CX-7 - 2006		YES	YES	YES	CAN H + Pin 6 CAN LO - Pin 14	Connected to connector OBD on left underneath steering column. Position (R and L) No. 6 and No. 14.
	CX-9 - 2007		YES	YES	YES	CAN H + Pin 6 CAN LO - Pin 14	Connected to connector OBD on left underneath steering column. Position (R and L) No. 6 and No. 14.
	Demio - 2005		YES	YES	YES	CAN H + Pin 6 CAN LO - Pin 14	Connected to connector OBD on left underneath steering column. Position (R and L) No. 6 and No. 14.
	MPV - 2004		YES	YES	YES	CAN H + Pin 6 - BLUE / WHITE CAN LO - Pin 14 - GREEN / BLACK	Connected to connector OBD on left underneath steering column. Position (R and L) No. 6 and No. 14.
	MX-6 - 2006		YES	YES	YES	CAN H + Pin 6 - BLUE / WHITE CAN LO - Pin 14 - GREEN / BLACK	Connected to connector OBD on left underneath steering column. Position (R and L) No. 6 and No. 14.
	MX-8 - 2004		YES	YES	YES	CAN H + Pin 6 CAN LO - Pin 14	Connected to connector OBD on left underneath steering column. Position (R and L) No. 6 and No. 14.
<b>Mercedes</b>							
	A - Class W168 - 2000		YES	YES	YES	CAN H + GREEN/WHITE CAN LO - BROWN	Remove the vehicle speedometer assembly. The CAN wires are located at the connection plugs. The CAN bus wiring is a twisted pair of wires. Connected in the door frame behind the kick plate, passenger's side or driver's side.
	A - Class W169 - 2006		YES	YES	YES	CAN H + BROWN / RED CAN LO - BROWN	The CAN bus wiring is a twisted pair of wires.
	A - Class W176 - 2012		YES	YES	YES	CAN H + BROWN / RED CAN LO - BROWN	The CAN wires are at the socket unit and in the driver's side all room (B Way Black Connector). The CAN bus wiring is a twisted pair of wires.
	B - Class W245 - 2005		YES	YES	YES	CAN H + BROWN / RED CAN LO - BROWN	Remove the door frame behind the kick plate, passenger's side or driver's side. The CAN bus wiring is a twisted pair of wires.
	B - Class W246 - 2011		YES	YES	YES	CAN H + BROWN / RED CAN LO - BROWN	Remove the door frame behind the kick plate, passenger's side or driver's side. The CAN bus wiring is a twisted pair of wires.
	C - Class W203 - 2000		YES	YES	YES	CAN H + GREEN/WHITE CAN LO - GREEN	Remove the lower driver's side under panel. Locate the ignition barrel (horn or control unit). The CAN bus wiring is a twisted pair of wires.
	C - Class W204 - 2007	Reverse only with auto gearbox	YES	YES	(A/UT/O)	CAN H + BROWN / RED CAN LO - BROWN	The wiring is located in the main loom behind the driver's side lower dash kick panel. The Reverse Gear output is only available on Automatic vehicles.
	C - Class W205 - 2013	NEW	YES	YES	(A/UT/O)	CAN H + BROWN / RED CAN LO - BROWN	The wiring is located in the main loom behind the driver's side lower dash kick panel. The Reverse Gear output is only available on Automatic vehicles.
	CL - 2007	Reverse only with auto gearbox	YES	YES	(A/UT/O)	CAN H + BROWN / RED CAN LO - BROWN	Remove the lower driver side under panel. The CAN wires are located at the black CANbus junction connector. The CAN bus wiring is a twisted pair of wires.
	CLK - 2002		YES	YES	YES	CAN H + BROWN / RED CAN LO + BROWN	Remove the lower driver's side under panel. The CAN wires are located in concentrator connector wires. The CAN bus wiring is a twisted pair of wires.
	CLA W117 - 2013	NEW	YES	YES	YES	CAN H + BROWN / RED CAN LO + BROWN	Remove the lower driver's side under panel. The CAN wires are located in concentrator connector wires. The CAN bus wiring is a twisted pair of wires.
	CLS - 2007		YES	YES	YES	CAN H + BROWN / RED CAN LO - BROWN	Remove the lower driver's side under panel. The CAN wires are located at the black CANbus junction connector. The CAN bus wiring is a twisted pair of wires.
	CLS W218 - 2011	NEW	YES	YES	(A/UT/O)	CAN H + BROWN / RED CAN LO - BROWN	Remove the lower driver's side under panel. The CAN wires are located at the black CANbus junction connector. The CAN bus wiring is a twisted pair of wires.
	E - Class W211 - 2000		YES	YES	YES	CAN H + BROWN / RED CAN LO - BROWN	Remove the lower driver's side under panel. The CAN wires are located in concentrator connector wires. The CAN bus wiring is a twisted pair of wires.
	E - Class W212 - 2009	Reverse only with auto gearbox	YES	YES	(A/UT/O)	CAN H + BROWN / RED CAN LO - BROWN	Remove the lower driver's side under panel. The CAN wires are located in concentrator connector black. The CAN bus wiring is a twisted pair of wires.
	E - Class W213 - 2012	NEW	YES	YES	(A/UT/O)	CAN H + BROWN / RED CAN LO - BROWN	Remove the lower driver's side under panel. The CAN wires are located in concentrator connector black. The CAN bus wiring is a twisted pair of wires.
	G - Class - 2009		YES	YES	YES	CAN H + BROWN / RED CAN LO - BROWN	Remove the lower passenger side under panel. The CANbus wires are located in concentrator connector black. The CAN bus wiring is a twisted pair of wires.
	GLA - Class - 2014	NEW	YES	YES	YES	CAN H + BROWN / RED CAN LO - BROWN	Remove the lower passenger side under panel. The CANbus wires are located in concentrator connector black. The CAN bus wiring is a twisted pair of wires.
	GLE - Class Coupe - 2015	NEW	YES	YES	YES	CAN H + BROWN / RED CAN LO - BROWN	Remove the lower passenger side under panel. The CANbus wires are located in concentrator connector black. The CAN bus wiring is a twisted pair of wires.
	GLK - Class - 2008	NEW	YES	YES	YES	CAN H + BROWN / RED CAN LO - BROWN	Remove the lower passenger side under panel. The CANbus wires are located in concentrator connector black. The CAN bus wiring is a twisted pair of wires.
	GLS - Class - 2008	NEW	YES	YES	YES	CAN H + BROWN / RED CAN LO - BROWN	Remove the lower passenger side under panel. The CANbus wires are located in concentrator connector black. The CAN bus wiring is a twisted pair of wires.
	M - Class - 1999		YES	YES	YES	CAN H + WHITE CAN LO - BROWN	Remove the lower driver's side under panel. The CAN wires are located at the control module. The CAN bus wiring is a twisted pair of wires.
	M - Class - 2008		YES	YES	YES	CAN H + BROWN / RED CAN LO - BROWN	Connected in the CANbus concentrator connector wires, behind the kick plate, passenger's side. The CAN bus wiring is a twisted pair of wires.
	M - Class W168 - 2011		YES	YES	YES	CAN H + BROWN / RED CAN LO - BROWN	Connected in the CANbus concentrator connector wires, behind the kick plate, passenger's side. The CAN bus wiring is a twisted pair of wires.
	R - Class - 2006		YES	YES	(A/UT/O)	CAN H + BROWN / RED CAN LO - BROWN	Remove the lower passenger side under panel. The CANbus wires are located in concentrator connector black. The CAN bus wiring is a twisted pair of wires.
	S - Class - 2000		YES	YES	YES	CAN H + BROWN / RED CAN LO - BROWN	Remove the lower driver side under panel. The CAN wires are located on the black CANbus junction connector. The CAN bus wiring is a twisted pair of wires.
	S - Class W221 - 2008		YES	YES	YES	CAN H + BROWN / RED CAN LO - BROWN	Remove the lower driver side under panel. The CAN wires are located at the black CANbus junction connector. The CAN bus wiring is a twisted pair of wires.
	S - Class W222 - 2013		YES	YES	YES	CAN H + BROWN / RED CAN LO - BROWN	Remove the lower driver side under panel. The CAN wires are located at the black CANbus junction connector. The CAN bus wiring is a twisted pair of wires.
	SL - Class - 2001		YES	YES	YES	CAN H + BROWN / RED CAN LO - BROWN	Remove the lower driver side under panel. The CAN wires are located at the black CANbus junction connector. The CAN bus wiring is a twisted pair of wires.
	SL - Class - 2012	NEW	YES	YES	YES	CAN H + BROWN / RED CAN LO - BROWN	Remove the lower driver side under panel. The CAN wires are located at the black CANbus junction connector. The CAN bus wiring is a twisted pair of wires.
	SLK - 2004		YES	YES	YES	CAN H + BROWN / RED CAN LO - BROWN	Remove the lower driver side under panel. The CAN wires are located at the black CANbus junction connector. The CAN bus wiring is a twisted pair of wires.
	SLK - 2011	NEW	YES	YES	YES	CAN H + BROWN / RED CAN LO - BROWN	Remove the lower driver side under panel. The CAN wires are located at the black CANbus junction connector. The CAN bus wiring is a twisted pair of wires.
	Sprinter - 2000		YES	YES	YES	CAN H + GREEN/WHITE CAN LO - BROWN	Remove the vehicle speedometer cover. The CAN wires are located at the connection plugs. The CAN bus wiring is a twisted pair of wires.
	Sprinter - 2008		YES	YES	YES	CAN H + BROWN / RED CAN LO - BROWN	Remove the lower driver side panel. The CAN wires are located in concentrator connector wires. The CAN bus wiring is a twisted pair of wires.
	Sprinter - 2014	NEW	YES	YES	YES	CAN H + BROWN / RED CAN LO - BROWN	Remove the lower driver side panel. The CAN wires are located in concentrator connector wires. The CAN bus wiring is a twisted pair of wires.
	V-Class - 2014	NEW	YES	YES	YES	CAN H + BROWN / RED CAN LO - BROWN	Remove the lower driver's side under panel. The CAN wires are located at near the kick panel. Also at the speedometer. The CAN bus wiring is a twisted pair of wires.
	Vaneo - 2000		YES	YES	YES	CAN H + BROWN / RED CAN LO - BROWN	Remove the lower driver's side under panel. The CAN wires are located at near the kick panel. Also at the speedometer. The CAN bus wiring is a twisted pair of wires.
	Vito - 2004		YES	YES	YES	CAN H + BROWN / RED CAN LO - BROWN	Remove the lower driver's side under panel. The CAN wires are located at near the kick panel. Also at the speedometer. The CAN bus wiring is a twisted pair of wires.
	Vito - 2015	NEW	YES	YES	YES	CAN H + BROWN / RED CAN LO - BROWN	Remove the lower driver's side under panel. The CAN wires are located at near the kick panel. Also at the speedometer. The CAN bus wiring is a twisted pair of wires.
	Viano - 2003		YES	YES	YES	CAN H + BROWN / RED CAN LO - BROWN	Remove the lower driver's side under panel. The CAN wires are located at near the kick panel. Also at the speedometer. The CAN bus wiring is a twisted pair of wires.
<b>Mercedes Truck</b>							
	Actros 2003		YES	YES	YES	CAN H + GREEN/WHITE CAN LO - GREEN	Remove the vehicle speedometer assembly. The CAN wires are located at the connection plugs. The CAN bus wiring is a twisted pair of wires. Connected in the door frame behind the kick plate, passenger's side or driver's side.
	Actro		YES	YES	YES	CAN H + BROWN / RED CAN LO - BROWN	The CAN bus wiring is a twisted pair of wires.
	Axor		YES	YES	YES	CAN H + BROWN / RED CAN LO - BROWN	The CAN wires are at the socket unit and in the driver's side all room (B Way Black Connector). The CAN bus wiring is a twisted pair of wires.
	Econic H - 2007		YES	YES	YES	CAN H + BROWN / RED CAN LO - BROWN	The CAN wires are at the socket unit and in the driver's side all room (B Way Black Connector). The CAN bus wiring is a twisted pair of wires.
<b>Mini</b>							
	Mini - 2001		YES	YES	YES	CAN H + YELLOW / BLACK CAN LO + YELLOW / BROWN	Remove the vehicle speedometer assembly. The CAN wires are located at the connection plugs. The CAN bus wiring is a twisted pair of wires.
	Mini - 2007		YES	(YES)	YES	CAN H + ORANGE / GREEN CAN LO - GREEN	Connector BLACK/DORRY 51 pin connector is located on the light control unit behind the driver side lower dash kick panel. Position (R and L) No. 46 and No. 45.
	Mini - 2014	NEW	YES	(YES)	YES	CAN HIGH: BLUE/RED CAN LOW: RED	Remove the lower passenger under glove box trim. Inside the FEM (Fused Electrical Module). The CAN BUS wiring is a twisted pair of wires. Connector: 12 pins WHITE Number 10. Position (R and L).
	Coastman - 2010		YES	(YES)	YES	CAN H + Pin 26 ORANGE / GREEN CAN LO + Pin 13 GREEN	Connector BLACK 52 pin connector is located in the junction box on the right side passenger glove compartment. Position (R and L) No. 26 and No. 13.
<b>Mitsubishi</b>							
	ASX - 2010		YES	YES	YES	CAN H + BLACK CAN LO WHITE	Remove the vehicle speedometer assembly. The CAN wires are located at the connection plugs. The CAN bus wiring is a twisted pair of wires.
	Cali - 2005		YES	YES	YES	CAN H + BROWN / RED CAN LO - Pin 14	Connected to connector OBD on left underneath steering column. Position (R and L) No. 6 and No. 14.
	L200 Evo 10 - 2008		YES	YES	YES	CAN H + GREEN CAN LO - BROWN	Remove the vehicle speedometer assembly. The CAN wires are located at the connection plugs. The CAN bus wiring is a twisted pair of wires.
	L200 - 2012		YES	YES	YES	CAN H + Pin 6 CAN LO - Pin 14	Connected to connector OBD on left underneath steering column. Position (R and L) No. 6 and No. 14.
	L200 - 2016	NEW	YES	YES	YES	CAN H + Pin 6 CAN LO - Pin 14	Connected to connector OBD on left underneath steering column. Position (R and L) No. 6 and No. 14.
	Grandis - 2004		YES	YES	YES	CAN H + Pin 6 - Pin 4 - RED / BLUE CAN LO + Pin 14 - Pin 3 - BLACK / BLUE	Connected to connector OBD on left underneath steering column. Position (R and L) No. 6 and No. 14.
	Outlander - 2007		YES	YES	YES	CAN H + GREEN (behind speedometer) - ORANGE CAN LO + PINK (behind speedometer) - WHITE	Remove the vehicle speedometer assembly. The CAN bus wiring is a twisted pair of wires. Or Radio Connector WHITE 20-Pin behind the radio CAN HIGH No. 8 ORANGE and CAN LOW No. 18 WHITE.
	Outlander - 2013		YES	YES	YES	CAN H + Pin 6 CAN LO - Pin 14	Connected to connector OBD on left underneath steering column. Position (R and L) No. 6 and No. 14.
	Space Star - 2013		YES	YES	YES	CAN H + Pin 6 CAN LO - Pin 14	Connected to connector OBD on left underneath steering column. Position (R and L) No. 6 and No. 14.

MagicWatch WPS910 & WPS900F Application & Functionality 03/2017

Table with columns: Manufacturer, Model, Note, Speed, Ignition, Reverse, Wire connections, Position. Rows include manufacturers like Nissan, Opel, Peugeot, and Porsche.

MagicWatch WPS910 & WPS900F Application & Functionality 03/2017

Manufacturer	Model	Note	Speed	Ignition	Reverse	Wire connections	Position
<b>Renault</b>							
Caplar	2013	NEW	YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
Clio	2007		YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
Clio	2012		YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
Espace	2003		YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
Espace	2015	NEW	YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
Kadjar	2015	NEW	YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
Kangoo	2009		YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
Koleos	2009		YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
Laguna (III)	2008		YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	The CAN wiring is located at the OBD socket, under a rubber cover below the ashtray. Position (H and L): No. 6 and No. 14
Laguna (III)	2008		YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	The CAN wiring is located at the OBD socket, under the cup holder in the below the centre arm rest. Position (H and L): No. 6 and No. 14
Master	2003		YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	The CAN wiring is located at the OBD socket, behind the drivers side lower dash panel. Position (H and L): No. 6 and No. 14
Master	2009		YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	The CAN wiring is located at the OBD socket, inside the glove compartment. Position (H and L): No. 6 and No. 14
Magnum	2001		YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	Remove the vehicle speedometer assembly. The CAN wires are located at the connection plugs. Position (H and L): No. 6 and No. 14
Magnum	2009		YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	The CAN wiring is located at the OBD socket, under the radio behind a plastic panel. Position (H and L): No. 6 and No. 14
Mobius	2003		YES	YES	YES	CAN H + ORANGE CAN/L0 + BROWN	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
Scenic	2004		YES	YES	YES	CAN H + BROWN / WHITE CAN/L0 + ORANGE / WHITE	Remove the vehicle speedometer assembly. The CAN wires are located at the connection plugs. Position (H and L): No. 6 and No. 14
Scenic	2009		YES	YES	YES	CAN H + PURPLE / RED CAN/L0 + WHITE / RED	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
Talisman	2015	NEW	YES	YES	YES	CAN H + PURPLE / RED CAN/L0 + WHITE / RED	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
Trafic	2003		YES	YES	YES	CAN H + PURPLE / RED CAN/L0 + WHITE / RED	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
Trafic	2014	NEW	YES	YES	YES	CAN H + PURPLE / RED CAN/L0 + WHITE / RED	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
Van Scenic	2002		YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	The CAN wiring is located at the OBD socket, under a rubber cover below the ashtray. Position (H and L): No. 6 and No. 14
Wind	2010		YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	The CAN wiring is located at the OBD socket, inside the glove box. Position (H and L): No. 6 and No. 14
Zoe	2013		YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	The CAN wiring is located at the OBD socket, inside the glove box. Position (H and L): No. 6 and No. 14
<b>Rover</b>							
75 / MG ZT	2000		YES			CAN H + YELLOW / BLACK CAN/L0 + YELLOW / BLACK	Remove the vehicle speedometer assembly. The CAN wires are located at the connection plugs. The CAN bus wiring is a twisted pair of wires.
75 (V8)	2000		YES			CAN H + YELLOW / BLACK CAN/L0 + YELLOW / BLACK	Remove the vehicle speedometer assembly. The CAN wires are located at the connection plugs. The CAN bus wiring is a twisted pair of wires.
<b>Saab</b>							
93	2006		YES	YES	YES	CAN H + GREEN CAN/L0 + BROWN / WHITE	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
95	2008		YES	YES	YES	CAN H + GREEN CAN/L0 + WHITE	Remove the vehicle Speed Box. The CAN wires are located at the Left Hand Main Loom. Position (H and L): No. 6 and No. 14
95	2010		YES	YES	YES	CAN H + GREEN / OBD Pin 1 CAN/L0 + BLACK / OBD Pin 4	The CAN wires are available at the OBD connector under the drivers dash. Position (H and L): No. 6 and No. 14
97	2008		YES	YES	YES	CAN H + GREEN CAN/L0 + CONNECT TO GROUND	Connected to connector OBD on left underneath steering column. Position (H and L): No. 1 and G.N.D. Or Position (H and L): No. 6 and No. 14.
<b>Scania</b>							
R570	2004		YES	YES	YES	CAN H + YELLOW CAN/L0 + WHITE	The CAN wiring can be found in the main loom under the passenger fuse box and also at the speedometer assembly. The CAN bus wiring is a twisted pair of wires.
R480	2004		YES	YES	YES	CAN H + YELLOW CAN/L0 + WHITE	The CAN wiring can be found in the main loom under the passenger fuse box and also at the speedometer assembly. The CAN bus wiring is a twisted pair of wires.
<b>Seat</b>							
Athenea	2000		YES	YES	YES	CAN H + ORANGE / BLACK or ORANGE / GREEN CAN/L0 + ORANGE / BROWN or ORANGE / BROWN	The CAN wires are located at the GREEN connector located at the rear of the speedometer. Remove the steering column housing. There are 2 x Torx screws securing the speedometer. The CAN wiring is a twisted pair.
Athenea	2010	NEW	YES	YES	YES	CAN H + ORANGE / BLACK or ORANGE / GREEN CAN/L0 + ORANGE / BROWN or ORANGE / BROWN	The CAN wires are located at the GREEN connector located at the rear of the speedometer. Remove the steering column housing. There are 2 x Torx screws securing the speedometer. The CAN wiring is a twisted pair.
Altea	2004		YES	YES	YES	CAN H + YELLOW CAN/L0 + BROWN	Remove the vehicle speedometer assembly. The CAN wires are located at the connection plugs. The CAN bus wiring is a twisted pair of wires.
Altea	2008		YES	YES	YES	CAN H + ORANGE / GREEN CAN/L0 + ORANGE / BROWN	Connector BLACK 12 pin (marked Q) located the lower drivers side under panel. Position (H and L): No. 15 and No. 16
Altea	2011		YES	YES	YES	CAN H + ORANGE / GREEN CAN/L0 + ORANGE / BROWN	Connector BROWN 52 pin connector located the lower drivers side under panel. Position (H and L): No. 15 and No. 16
Eneo	2009		YES	YES	YES	CAN HIGH ORANGE-GREEN CAN LOW ORANGE-BROWN	Connector GREY/VIOLET 32 pin connector connected to Black color unit (labeled underneath dashboard drivers side). Position (H and L): No. 13 and No. 12
Ibiza	2003		YES	YES	YES	CAN H + ORANGE / GREEN CAN/L0 + ORANGE / BROWN	Connector BLACK 19 pin (marked X2) the connector is located the lower drivers side under panel. Position (H and L): No. 12 and No. 9.
Ibiza	2010		YES	YES	YES	CAN H + ORANGE / GREEN CAN/L0 + ORANGE / BROWN	Connector WHITE controller box, the connector is located the lower drivers side under panel. Position (H and L): No. 6 and No. 7.
Leon	2004		YES	YES	YES	CAN H + ORANGE / GREEN CAN/L0 + ORANGE / BROWN	Connector BLACK 12 pin (marked Q) the connector is located the lower drivers side under panel. Position (H and L): No. 15 and No. 16
Leon	2011		YES	YES	YES	CAN H + ORANGE / GREEN CAN/L0 + ORANGE / BROWN	Connector BROWN 52 pin connector is located the lower drivers side under panel. Position (H and L): No. 15 and No. 16
Mi	2012	NEW	YES	YES	YES	CAN H + ORANGE / GREEN CAN/L0 + ORANGE / BROWN	Connector Fuses below the rear of the WHITE connector on main unit, the connector is located the lower drivers side under panel.
<b>Skoda</b>							
Octigo	2012		YES	YES	YES	CAN H + ORANGE / GREEN CAN/L0 + ORANGE / BROWN	Connector BLACK 18 pin (marked X2) the connector is located the lower drivers side under panel. Position (H and L): No. 12 and No. 9.
Fabia	2002		YES	YES	YES	CAN H + ORANGE / GREEN CAN/L0 + ORANGE / BROWN	Connector BLACK 18 pin (marked X2) the connector is located the lower drivers side under panel. Position (H and L): No. 12 and No. 9.
Fabia	2010		YES	YES	YES	CAN H + ORANGE / GREEN CAN/L0 + ORANGE / BROWN	Connector WHITE controller box, the connector is located the lower drivers side under panel. Position (H and L): No. 6 and No. 7.
Fabia	2014	NEW	YES	YES	YES	CAN H + ORANGE / GREEN CAN/L0 + ORANGE / BROWN	Connector Fuses below the rear of the WHITE connector on main unit, the connector is located the lower drivers side under panel.
Octavia	2005		YES	YES	YES	CAN H + ORANGE / GREEN CAN/L0 + ORANGE / BROWN	Connector BLACK 12 pin (marked Q) the connector is located the lower drivers side under panel. Position (H and L): No. 8 and No. 7.
Octavia III	2009		YES	YES	YES	CAN H + ORANGE / GREEN or ORANGE / PURPLE CAN/L0 + ORANGE / BROWN	Connector BROWN 52 pin connector is located the lower drivers side under panel. Position (H and L): No. 15 and No. 16
Octavia III	2013		YES	(YES)	YES	CAN H + ORANGE / GREEN CAN/L0 + ORANGE / BROWN	Connector BLACK 19 pin connector is located the lower drivers side under panel Position (H and L): No. 8 and No. 7. Also found the wiring harness coming from the driver door grommet.
Roomster	2009		YES	YES	YES	CAN H + ORANGE / GREEN CAN/L0 + ORANGE / BROWN	Connector BLACK 18 pin (marked X2) the connector is located the lower drivers side under panel. Position (H and L): No. 12 and No. 9.
Sapato	2008		YES	YES	YES	CAN H + ORANGE / GREEN CAN/L0 + ORANGE / BROWN	Connector BLACK 18 pin (marked X2) the connector is located the lower drivers side under panel. Position (H and L): No. 12 and No. 9.
Sapato	2015	NEW	YES	YES	YES	CAN H + ORANGE / GREEN CAN/L0 + ORANGE / BROWN	Connector BLACK 19 pin connector is located the lower drivers side under panel Position (H and L): No. 8 and No. 7. Also found the wiring harness coming from the driver door grommet.
Yeti	2009		YES	YES	YES	CAN H + ORANGE / GREEN CAN/L0 + ORANGE / BROWN	Connector BROWN 52 pin connector is located the lower drivers side under panel. Position (H and L): No. 15 and No. 16
<b>Smart</b>							
FourTwo	2007		YES	YES	YES	CAN H + GREEN / WHITE CAN/L0 + GREEN	Remove the vehicle audio unit. The CAN wires are located in the loom running vertical towards the heater panel at the top of the dash. The CAN bus wiring is a twisted pair of wires, coloured as below.
<b>Ssangyong</b>							
Actyon	2012		YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
Korando	2010		YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
Rodiuc	2015	NEW	YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
<b>Subaru</b>							
Forester	2009		YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
Impreza	2008		YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
Legacy	2009		YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
Outback	2009		YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
XV	2012		YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
<b>Suzuki</b>							
Alto	2009		YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
Grand Vitara	2006		YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
S-Cross	2014		YES	YES	YES	CAN H + RED CAN/L0 + WHITE	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
Spirax	2009		YES	YES	YES	CAN H + RED/BLACK CAN/L0 + WHITE/BLACK	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
Swift	2005		YES	YES	YES	CAN H + RED CAN/L0 + WHITE/BLACK	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
Swift	2010	NEW	YES	YES	YES	CAN H + RED CAN/L0 + Pin 14 - WHITE	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
SX4	2006		YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14 - WHITE	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
Vitara	2015	NEW	YES	YES	YES	CAN H + RED CAN/L0 + Pin 14 - WHITE	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
<b>Tesla</b>							
Model S	2013	NEW	YES	YES	YES	CAN H + PURPLE / WHITE CAN/L0 + PURPLE	Undo the under panel / pocket trim below the central display unit and located the white connector.
<b>Toyota</b>							
Avenis	2009		YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
Auris	2007		YES	YES	YES	CAN H + GREEN CAN/L0 + WHITE	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
Auris	2013	NEW	YES	YES	YES	CAN H + GREEN CAN/L0 + WHITE	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
BB	2007		YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	The CAN wiring is located at the OBD socket, near the centre console under drivers side dash. Position (H and L): No. 6 and No. 14
Casi	2016	NEW	YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	The CAN wiring is located at the OBD socket, near the centre console under the gearchange lever. Position (H and L): No. 6 and No. 14
Etna	2006		YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 6	The CAN wiring is located at the OBD socket, near the centre console under the gearchange lever. Position (H and L): No. 6 and No. 14
HILLUX	2015	NEW	YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
Land Cruiser	2009		YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
Prius	2005		YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
Prius	2009		YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
Prius	2015	NEW	YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
RAV 4	2006		YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
Vans	2011		YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
Vans	2006		YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 6	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
Vans	2011		YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14

MagicWatch WPS910 & WPS900F Application & Functionality 03/2017

Manufacturer	Model	Note	Speed	Ignition	Reverse	Wire connections	Position
<b>Volkswagen</b>							
	Amarok : 2011			YES	YES	CAN H = ORANGE / GREEN CAN L0 = ORANGE / BROWN	Remove the lower driverside under panel. The CAN wires are a twisted pair located in the main loom WHITE connector 73 pins near the steering column. The CAN may also be available at the audio Quattrolock connector
	Beetle : 1999			YES	YES	CAN H = ORANGE / BLACK CAN L0 = ORANGE / BROWN	Remove the vehicle speedometer assembly. The CAN wires are located at the connection plugs. The CAN bus wiring is a twisted pair of wires.
	Beetle : 2004			YES	YES	CAN H = ORANGE / GREEN CAN L0 = ORANGE / BROWN	Connector BLACK 12 pin (marked G) the connector is located the lower driverside under panel Position (H and L): Nr. 8 and Nr. 7.
	Beetle : 2012			YES	YES	CAN H = ORANGE / GREEN CAN L0 = ORANGE / BROWN	Remove the lower driverside under panel. The CAN wires are a twisted pair located in the main loom WHITE connector 73 pins near the steering column. The CAN may also be available at the audio Quattrolock connector
	Caddy : 2005			YES	YES	CAN H = ORANGE / GREEN CAN L0 = ORANGE / BROWN	Connector BLACK 12 pin (marked G) the connector is located the lower driverside under panel Position (H and L): Nr. 8 and Nr. 7.
	Caddy : 2010			YES (YES*)	YES	CAN H = ORANGE / GREEN CAN L0 = ORANGE / BROWN	Connector BROWN 12 pin the connector is located the lower driverside under panel Position (H and L): Nr. 15 and Nr. 16.
	Caddy : 2016	NEW		YES (YES*)	YES	CAN H = ORANGE / GREEN CAN L0 = ORANGE / BROWN	Connector BROWN 12 pin the connector is located the lower driverside under panel Position (H and L): Nr. 15 and Nr. 16.
	Caravelle : 2004			YES (YES*)	YES	CAN H = ORANGE / GREEN CAN L0 = ORANGE / BROWN	Connector BROWN 12 pin the connector is located the lower driverside under panel Position (H and L): Nr. 8 and Nr. 7.
	Ceater : 2008			YES (YES*)	AUTO	CAN H = BROWN / RED CAN L0 = BROWN	Remove the lower driver side panel. The CAN wires are located in connector connector wires. The CAN bus wires are twisted pair of wires.
	Ceater : 2014	NEW		YES (YES*)	AUTO	CAN H = BROWN / RED CAN L0 = BROWN	Remove the lower driver side panel. The CAN wires are located in connector connector wires. The CAN bus wires are twisted pair of wires.
	Eos : 2008			YES (YES*)	YES	CAN H = ORANGE / GREEN CAN L0 = ORANGE / BROWN	Connector BLACK 12 pin (marked G) the connector is located the lower driverside under panel Position (H and L): Nr. 8 and Nr. 7.
	Golf V : 2004			YES (YES*)	YES	CAN H = ORANGE / GREEN CAN L0 = ORANGE / BROWN	Connector BLACK 12 pin (marked G) the connector is located the lower driverside under panel Position (H and L): Nr. 8 and Nr. 7.
	Golf VI : 2009			YES (YES*)	YES	CAN H = ORANGE / GREEN CAN L0 = ORANGE / BROWN	Connector BROWN 12 pin the connector is located the lower driverside under panel Position (H and L): Nr. 15 and Nr. 16.
	Golf VII : 2013			YES (YES*)	YES	CAN H = ORANGE / GREEN CAN L0 = ORANGE / BROWN	Connector BLACK 12 pin (marked G) the connector is located the lower driverside under panel Position (H and L): Nr. 8 and Nr. 7. Also found the wiring harness coming from the driver door grommet.
	Golf Plus : 2005			YES (YES*)	YES	CAN H = ORANGE / GREEN CAN L0 = ORANGE / BROWN	Connector BLACK 12 pin (marked G) the connector is located the lower driverside under panel Position (H and L): Nr. 8 and Nr. 7.
	Golf Plus : 2009			YES (YES*)	YES	CAN H = ORANGE / GREEN CAN L0 = ORANGE / BROWN	Connector BROWN 12 pin the connector is located the lower driverside under panel Position (H and L): Nr. 15 and Nr. 16.
	Jetta : 2012	NEW		YES (YES*)	YES	CAN H = ORANGE / BLACK CAN L0 = ORANGE / BROWN	Remove the vehicle speedometer assembly. The CAN wires are located at the connection plugs. The CAN bus wiring is a twisted pair of wires.
	Passat : 2002			YES (YES*)	YES	CAN H = ORANGE / BLACK CAN L0 = ORANGE / BROWN	Remove the vehicle speedometer assembly. The CAN wires are located at the connection plugs. The CAN bus wiring is a twisted pair of wires.
	Passat : 2005			YES (YES*)	YES	CAN H = ORANGE / GREEN CAN L0 = ORANGE / BROWN	Connector BLACK 12 pin (marked G) the connector is located the lower driverside under panel Position (H and L): Nr. 8 and Nr. 7.
	Passat : 2011			YES (YES*)	YES	CAN H = ORANGE / GREEN CAN L0 = ORANGE / BROWN	Connector BROWN 12 pin the connector is located the lower driverside under panel Position (H and L): Nr. 15 and Nr. 16.
	Passat : 2015	NEW		YES (YES*)	YES	CAN H = ORANGE / GREEN CAN L0 = ORANGE / BROWN	Connector BLACK 12 pin (marked G) the connector is located the lower driverside under panel Position (H and L): Nr. 8 and Nr. 7. Also found the wiring harness coming from the driver door grommet.
	Polo : 2005			YES (YES*)	YES	CAN H = ORANGE / GREEN CAN L0 = ORANGE / BROWN	Connector BLACK 18 pin (marked E2) the connector is located the lower driverside under panel Position (H and L): Nr. 12 and Nr. 9.
	Polo : 2010			YES	YES	CAN H = ORANGE / GREEN CAN L0 = ORANGE / BROWN	Connector WHITE controller box, the connector is located the lower driverside under panel Position (H and L): Nr. 8 and Nr. 7.
	Polo : 2015	NEW		YES	YES	CAN H = ORANGE / GREEN CAN L0 = ORANGE / BROWN	Connector BLACK 73 pin the connector is located the lower driverside under panel Position (H and L): Nr. 8 and Nr. 7. Also found the wiring harness coming from the driver door grommet.
	Routan : 2009			YES (YES*)	YES	CAN H = WHITE / GREY CAN L0 = WHITE / ORANGE	The CAN bus wiring is a twisted pair of wires, located at the radio wiring connector. Remove the radio panel (striped) and under the radio for access.
	Scirocco : 2009			YES (YES*)	YES	CAN H = ORANGE / GREEN CAN L0 = ORANGE / BROWN	Connector BLACK 12 pin (marked G) the connector is located the lower driverside under panel Position (H and L): Nr. 8 and Nr. 7.
	Sharan : 2002			YES	YES	CAN H = ORANGE / BLACK or ORANGE / BROWN CAN L0 = ORANGE / GREEN or ORANGE / BROWN	The CAN wires are located at the GREEN connector located at the rear of the speedometer. Remove the steering column housing. There are 2 x Torx screws securing the speedometer. The CAN wiring is a twisted pair.
	Sharan : 2010			YES	YES	CAN H = ORANGE / GREEN CAN L0 = ORANGE / BROWN	The CAN wires are located in the steering column loom. The CAN wiring is a twisted pair.
	Tiguan : 2007 (3009)			YES (YES*)	YES	CAN H = ORANGE / PURPLE CAN L0 = ORANGE / BROWN	Connector BLACK 12 pin (marked G) the connector is located the lower driverside under panel Position (H and L): Nr. 8 and Nr. 7.
	Tiguan : 2016	NEW		YES (YES*)	YES	CAN H = ORANGE / GREEN CAN L0 = ORANGE / BROWN	Connector BLACK 13 pin the connector is located the lower driverside under panel Position (H and L): Nr. 8 and Nr. 7. Also found the wiring harness coming from the driver door grommet.
	Touareg : 2004			YES (YES*)	YES	CAN H = ORANGE / GREEN CAN L0 = ORANGE / BROWN	Remove the vehicle speedometer assembly. The CAN wires are located at the connection plugs. The CAN bus wiring is a twisted pair of wires.
	Touareg : 2011			YES (YES*)	YES	CAN H = ORANGE / GREEN CAN L0 = ORANGE / BROWN	Remove the lower driverside under panel. The CAN wires are a twisted pair located in the main loom 'C' BROWN connector 16 pins near the steering column.
	Touareg : 2015	NEW		YES (YES*)	YES	CAN H = ORANGE / GREEN CAN L0 = ORANGE / BROWN	Connector BLACK 12 pin (marked G) the connector is located the lower driverside under panel Position (H and L): Nr. 8 and Nr. 7. Connector BLACK 73 pin the connector is located the lower driverside under panel Position (H and L): Nr. 8 and Nr. 7. Also found the wiring harness coming from the driver door grommet.
	Transporter : 2004			YES (YES*)	YES	CAN H = ORANGE / GREEN CAN L0 = ORANGE / BROWN	Connector BROWN 12 pin the connector is located the lower driverside under panel Position (H and L): Nr. 8 and Nr. 7.
	Transporter : 2015	NEW		YES (YES*)	YES	CAN H = ORANGE / GREEN CAN L0 = ORANGE / BROWN	Connector Fuses behind the radio or the WHITE connector on main unit, the connector is located the lower driverside under panel.
	Up : 2012	NEW		YES (YES*)	YES	CAN H = ORANGE / GREEN CAN L0 = ORANGE / BROWN	Connector Fuses behind the radio or the WHITE connector on main unit, the connector is located the lower driverside under panel.
<b>Volvo</b>							
	C30 : 2007			YES	YES	CAN H = Pin 3 CAN L0 = Pin 11	Connected to connector OBD on left underneath steering column. Position (H and L): Nr. 3 and Nr. 11.
	C70 : 2001			YES	YES	CAN H = Pin 3 CAN L0 = Pin 11	Connected to connector OBD on left underneath steering column. Position (H and L): Nr. 3 and Nr. 11.
	S40 : 2005			YES	YES	CAN H = Pin 3 CAN L0 = Pin 11	Connected to connector OBD on left underneath steering column. Position (H and L): Nr. 3 and Nr. 11.
	S60 : 2001			YES	YES	CAN H = Pin 3 CAN L0 = Pin 11	Connected to connector OBD on left underneath steering column. Position (H and L): Nr. 3 and Nr. 11.
	S60 : 2010			YES	YES	CAN H = Pin 3 CAN L0 = Pin 11	Connected to connector OBD on left underneath steering column. Position (H and L): Nr. 3 and Nr. 11.
	S90 : 2016	NEW		YES	YES	CAN H = Pin 3 CAN L0 = Pin 11	Connected to connector OBD on left underneath steering column. Position (H and L): Nr. 3 and Nr. 11.
	V40 : 2012	NEW		YES	YES	CAN H = Pin 3 CAN L0 = Pin 11	Connected to connector OBD on left underneath steering column. Position (H and L): Nr. 3 and Nr. 11.
	V50 : 2005			YES	YES	CAN H = Pin 3 CAN L0 = Pin 11	Connected to connector OBD on left underneath steering column. Position (H and L): Nr. 3 and Nr. 11.
	V70 : 2000			YES	YES	CAN H = Pin 3 CAN L0 = Pin 11	Connected to connector OBD on left underneath steering column. Position (H and L): Nr. 3 and Nr. 11.
	V70 : 2011			YES	YES	CAN H = Pin 3 CAN L0 = Pin 11	The CAN wiring is located at the OBD socket, near the centre console under the gearchange lever Position (H and L): Nr. 3 and Nr. 11.
	V90 : 2016	NEW		YES	YES	CAN H = Pin 3 CAN L0 = Pin 11	The CAN wiring is located at the OBD socket, near the centre console under the gearchange lever Position (H and L): Nr. 3 and Nr. 11.
	X300 : 2010			YES	YES	CAN H = Pin 3 CAN L0 = Pin 11	Connected to connector OBD on left underneath steering column. Position (H and L): Nr. 3 and Nr. 11.
	X30 : 2000			YES	YES	CAN H = Pin 3 CAN L0 = Pin 11	Connected to connector OBD on left underneath steering column. Position (H and L): Nr. 3 and Nr. 11.
	X30 : 2011			YES	YES	CAN H = Pin 3 CAN L0 = Pin 11	Connected to connector OBD on left underneath steering column. Position (H and L): Nr. 3 and Nr. 11.
	X30 : 2009			YES	YES	CAN H = Pin 3 CAN L0 = Pin 11	Connected to connector OBD on left underneath steering column. Position (H and L): Nr. 3 and Nr. 11.
	X30 : 2016	NEW		YES	YES	CAN H = Pin 3 CAN L0 = Pin 11	Connected to connector OBD on left underneath steering column. Position (H and L): Nr. 3 and Nr. 11.
<b>Volvo Truck</b>							
	FM12 : 2002			YES	YES	CAN H = Pin 3 CAN L0 = Pin 11	Connected to connector OBD on left underneath steering column. Position (H and L): Nr. 3 and Nr. 11.

Column IGNITION  
For the vehicle applications shown with a (YES\*) in the ignition column, the system activates when the ignition is turned on and will remain live for 30 seconds.

Column REVERSE  
The meaning of (MANC) or (AUTOC) in the column CLUTCH.  
The meaning of (NC) in the clutch column is the clutch signal is available only on vehicles equipped with OEM cruise control.